

OBD PLUG

Quick Start Guide



INSTANT VEHICLE TRACKING
LINXUP



WE'RE CONFIDENT WE CAN MAKE IT RIGHT!

If you have any questions or problems with your GPS tracker, please give us a call before you make a return.

Linxup Customer Support Phone: 1-877-732-4980

Email: support@linxup.com

How are we doing? We'd love to know.

We hope you will be pleased with your order and the service you receive. We love to hear from customers about features they love, and ways we can continue to improve your experience. Leave us a review where you made your purchase. Thank you!

For more valuable information, please like us on Facebook, and follow us on Twitter and LinkedIn. You can also check out our blog at www.linxup.com/blog



Activate Your Device

1 Open a web browser and go to:
www.linxup.com/getstarted

2 Create an account, or log in to your existing account.

New Customers
Fill out the following to complete your registration:

Activation Code:

E-mail Address:

Create Your Password:

Confirm Password:

☐ I agree to the [Terms & Conditions](#)

Next

Already a Customer?
Simply log in and we'll walk you through the process of adding your new units.

Email Address:

Password:

Sign In

[Forgot Your Password?](#)

If not already on file, you may be prompted for your billing information.

Here's a copy of your device activation code:

Sticker Goes Here

3 Follow the instructions for activating your device(s).

Make sure the activation code on your device matches the code on screen. Or, if your activation code does not show up re-enter it and press continue.




Install Your Plug-In Tracking Device

4 Locate the OBDII port of your vehicle and connect your device.

If you need help locating the connector, please reference your vehicle's owner manual.

You may use the enclosed zip tie to secure the device and prevent tampering.

When removing the device from your vehicle, make sure you grasp the device as close to the port as possible.



5 Start your vehicle, and check the lights on the GPS.

Cell (Orange)	Fast Blinking	Searching for a cell network
	Slow Blinking	Connected to network
	Off	Cell modem off (sleep mode), or disconnected
(Blue)	Internal Use Only	
GPS (Green)	Blinking	GPS lock (connected to satellites)
	Off	No GPS signal / Acquiring satellites

Your vehicle must be outside and not in a covered area so that it will receive GPS signal. When working properly, the orange and green lights will be on. You should see your car's location on the map (may take up to two hours).


IMPORTANT NOTICE: remove device before jump starting the vehicle.

Get to Know the Linxup System



Setup

Customize the Linxup system to make it work best for you.




Set thresholds for speeding alerts and authorized hours.

Click to edit.



Alerts

Use the Alerts section to review all alerts that occur within defineable dates.




Click the address to see the location on a map.



Report

Review all fleet reports from the fleet activity dashboard.



Maintenance

Make vehicle maintenance easier with scheduled maintenance reminders.



Vehicle	Service Type	Service Interval	Next Service Due
Vehicle 2	General Service	Every 15,000 miles	9,902 miles overdue
Vehicle 4	Preventive Maintenance	Every 5,000 miles	543 miles overdue
Vehicle 1	Oil Change	Every 120 days	6 days overdue
Vehicle 2	General Service	Every 10 days	4 days to go
Vehicle 3	General Service	Every 30 days	30 days to go
Vehicle 1	Tire Rotation		in go
Vehicle 4	Scheduled Service		
Vehicle 2	Scheduled Service		
Vehicle 1	Preventive Maintenance		
Vehicle 2	Preventive Maintenance		




Map

Locate your vehicle at all times, view its history, and manage your geofences.



Need help? Click the 'Help' icon, sign up for a webinar, or connect with a customer service agent.

Use Route Replay to coach your driver by reviewing their driving history.



Locate your vehicle at all times.

A geofence can be an office, job-site, or a restricted area and is a virtual boundary on the map.



Download now! Linxup Mobile App

Track and monitor fleet driving with:
Alerts
Real-time GPS tracking
Driving report card

